

Storleksguide MSE1-A 2+1 kr-130

Rw 44 dB/Rw+Ctr 37 dB
(4 mm glas)

Modulbredd

	4	5	6	7	8	9	10	11	12	13	14	15	16	17
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23

Rw 47 dB/Rw+Ctr 41-43 dB
(6 mm glas, inner och/eller ytter)

Modulbredd

	4	5	6	7	8	9	10	11	12	13	14	15	16	17
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23

Rw 48 dB/Rw+Ctr 44 dB
(6 mm innerglas, 8 mm ytterglas)

Modulbredd

	4	5	6	7	8	9	10	11	12	13	14	15	16	17
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23

forts.

forts.

Storleksguide MSE1-A 2+1 kr-170

Rw 48 dB/Rw+Ctr 42 dB
(4 mm glas)

Modulbredd

	4	5	6	7	8	9	10	11	12	13	14	15	16	17
Modulhöjd	5						
	6						
	7					
	8				
	9			
	10		
	11	
	12
	13
	14
	15
	16
	17
	18
	19
	20
	21
	22
	23

Rw 48-49 dB/Rw+Ctr 44-45 dB
(6 mm glas, inner och/eller ytter)

Modulbredd

	4	5	6	7	8	9	10	11	12	13	14	15	16	17
Modulhöjd	5						
	6						
	7					
	8				
	9			
	10		
	11	
	12
	13
	14
	15
	16
	17
	18
	19
	20
	21
	22
	23

Rw 49 dB/Rw+Ctr 46 dB
(6 mm innerglas, 8 mm ytterglas)

Modulbredd

	4	5	6	7	8	9	10	11	12	13	14	15	16	17
Modulhöjd	5						
	6						
	7					
	8				
	9			
	10		
	11	
	12
	13
	14
	15
	16
	17
	18
	19
	20
	21
	22
	23

forts.

forts.

Storleksguide MSE1-A 2+1 kr-210

Rw 49 dB/Rw+Ctr 44 dB
(4 mm glas)

Modulbredd

		4	5	6	7	8	9	10	11	12	13	14	15	16	17
Modulhöjd	5
	6
	7
	8
	9
	10
	11
	12
	13
	14
	15
	16
	17
	18
	19
	20
	21
	22
	23

Rw 50 dB/Rw+Ctr 45-46 dB
(6 mm glas, inner och/eller ytter)

Modulbredd

		4	5	6	7	8	9	10	11	12	13	14	15	16	17
Modulhöjd	5
	6
	7
	8
	9
	10
	11
	12
	13
	14
	15
	16
	17
	18
	19
	20
	21
	22
	23

Rw 51 dB/Rw+Ctr 47 dB
(6 mm innerglas, 8 mm ytterglas)

Modulbredd

		4	5	6	7	8	9	10	11	12	13	14	15	16	17
Modulhöjd	5
	6
	7
	8
	9
	10
	11
	12
	13
	14
	15
	16
	17
	18
	19
	20
	21
	22
	23